

HP-41C Wand Byte-Loading Program by Steven R. Conn
PPC Calculator Journal Vol 8 No 3 Page 21 May 1981
Modified version - requires PPC ROM to run program

```
01 LBL "WB"      ;Wand Byte-Loading Program
02 FIX 0
03 CF 28
04 CF 29
05 "# OF BYTES?"
06 XEQ 00
07 7
08 /
09 INT
10 1
11 +
12 7
13 *
14 6
15 +
16 "LOAD "
17 ARCL X
18 "- +'S"
19 TONE 9
20 PROMPT
21 LBL "IL"      ;Initialize Loading
22 XROM 10,23 ;L- (Load Portion of LB)
23 LBL "WL"      ;Wand Load Bytes
24 "SCN SHIFT "
25 ARCL 06
26 TONE 9
27 XEQ 00
28 64
29 *
30 "SCN BYTE "
31 ARCL 06
32 AVIEW
33 TONE 9
34 XROM 27,05 ;WNDSCN
35 2
36 X=Y?
37 CF 09
38 RDN
39 RDN
40 RCL 01
41 +
42 XROM 10,24 ;B (Store Portion of LB)
43 GTO "WL"      ;Wand Load Bytes
44 LBL 00
45 AVIEW
46 CF 22
47 TONE 9
48 LBL 01
49 PSE
50 FC?C 22
51 GTO 01
52 RTN
53 END
```

0087C000F30057429C00A91CA91DFB23204F46204259544553
3FE00000174368114017421640F54C4F4144209B73F52D202B
27539F098EC000F300494CA297C000F300574CFA53434E2053
48494654209B069F09E00000161442F953434E204259544520
9B067E9F09A6C51278A90975752140A2981DF2574C017EA916
9F090289AB16B20085C0000DE9

135 BYTES

HP-41C Wand Byte-Loading 2 by Steven R. Conn PPC V8 N3 P21 May 1981

Program Registers Needed: 20

Row 1 (1 - 5)




Row 2 (5 - 6)



Row 3 (6 - 16)



Row 4 (16 - 19)



Row 5 (20 - 23)



Row 6 (23 - 24)



Row 7 (25 - 30)



Row 8 (30 - 34)



Row 9 (34 - 43)



Row 10 (43 - 51)



Row 11 (51 - 53)

