## ADVANCE SCHOOLS, Inc.

## No. 56386

Operates on standard 117VAC 50/60 cycles per second AC power and delivers one of four filtered DC voltages at 150 milliamps. (4.5V, 6V, 9V, or 12V)

- 1. Make sure selector switch is:
  OFF before plugging into wall
  OFF when not in use
  OFF when wiring up the output connections
- 2. When 4.5V or 9V are needed put selector switch up and voltage switch to right (9%) or left (4.5V).
- 3. When 6V or 12V are needed, put selector switch down and voltage switch to right (12V) or left (6V).
- 4. Pilot light will be on when unit is on.

## Schematic Diagram

