

Cut out a pair of these barcode strips and align outside an X and Y axis graph area. Place the straight edge towards the inside of the graph so the bar codes lie close to the actual axes themselves. Always have the zero code (all thin bars) end facing the origin of the graph. This is the upper end of the X-axis strips and the lower end of the Y-axis strips. The tall strips offer .04 inch resolution, and the short ones offer .025 inch resolution.

Place the 'STOP' code (WNDSCN #255) onto the upper guide sheet for ending data entry (see article 'The 41C Wand as a Digitizer').

X Axis

Y Axis

STOP



TO SEE HOW
SCALES WORK
TRY THIS
ROUTINE.

```
01 LBL 01
02 LBL 01
03 WNDSCN
04 GTO 01
05 END
```

X AXIS STRIP

Y AXIS STRIP